

HE-6

RT ELEVATION KIT 3500'+

HE-6

Change out primary spring and Button or Roller helix

Use stock clicker #4.

Use stock secondary spring.

Use stock gearing or lower.

Calibrate with Stock skidoo drive belt

Primary spring - 200/330

If running mod RT with big bore and/or pipes, contact me for application details.

TROUBLESHOOTING

=====

When contacting me with a technical question, please include your FULL NAME/PHONE NUMBER and setup.

Feedback please

www.mxzx-revzone.com